


CROSLEY®



CK-1

910-204700-003


This Record Cleaning Kit includes:

- Handcrafted wooden anti - static record cleaning brush
- One 25cc bottle of distilled water
- 3 Replacement styluses (styli)


Instructions for cleaning

Apply 3-6 drops of the distilled water along the leading edge of the cleaning brush. Ensure that the drops are absorbed into the fabric, rubbing the drops in using the bottom of the bottle.

Position the cleaning brush on the outside edge of the record. Gently contact the record with the damp leading edge of the brush. The turntable motor may be assisted by gently turning the record with your finger on the label.




Allow the damp leading edge to contact the record for about three revolutions. Dry the record with a simple rolling movement of the handle, allowing for the middle and back edge of the brush to contact the album for several revolutions, assuring thorough drying.



Instructions for replacing Stylus

First remove the needle; hold the Tone Arm steady while pulling down on the top front edge of the red plastic part. It may help to use a fingernail. Rotate the front down and pull the red plastic part off as shown.



To replace the needle, push the red plastic part on at the angle shown. Then rotate the front up until it clicks into position.

